

The drawing shown is a depiction of the installation of a STILE Stainless shower tray with Hardieglaze or Seratone wall linings.

Refer to the Stile Stainless Installation instructions for the tray installation methods.

Hardieglaze or Seratone Installation

The drawing shown is a depiction of the installation of a STILE Stainless shower tray with Hardieglaze or Seratone wall linings.

Refer to the James Hardie Hardieglaze Installation Manual or Laminex Seratone Installation Manual for specific installation information and methods of the respective wall linings.

Refer to the Stile Stainless Installation instructions for the tray installation methods.

Impresa Tile Showers Ltd. Is not responsible for the installation nor performance of Hardieglaze or Seratone and does not provide any warranties for either product.

Wall Framing

Wet Area Plasterboard
10mm or Fibre Cement Board 9mm

Waterproofing Membrane (Optional)

Hardieglaze or Seratone Wall Lining Adhered to Wallboard or Waterproofed Wallboard

Nog around Tray Perimeter

8mm gap between Wallboard and Lining

Side Upstand 110mm min. off Floor

Hardieglaze or Seratone Bottom Edge

Stile Stainless Tray

Tray Side Upstand

Glazing Channel

Hardieglaze or Seratone

10mm Frameless Glass

Threshold Width 50mm

Silicone Sealant

Tile or Vinyl Flooring

Tray Height 60mm

Concrete Slab

Fibreglass Reinforcement

Tray Support Pad. Factory-adhered

Easy- Clean Waste ECW9050
Inlet dia. 90mm
Outlet dia. 40 or 50mm
Depth 120mm

Silicone Sealant

Waterproofing if tile utilised

18mm Step in Tray

STILE STAINLESS