

SHOWER TRAY INSTALLATION RECOMMENDED ADHESIVES

- (A) Ardex NZ -- **ARDEX X77**
 - (B) Australasian Tiling Adhesives -- **AUSFLEX GOLD**
 - (C) Construction Chemicals NZ -- **DURAFLEX**
 - (D) ASA Bostik NZ -- **CONFLEX**
 - (E) Laticrete -- **LATAFLEX GOLD**
 - (F) Cemix Products -- **RUBBERFLEX**
 - (G) Davco -- **ULTRAFLEX**
-

TRAY INSTALLATION TO FLOOR

Apply one of the recommended thinset tile adhesives below to a minimum 10mm-thickness to each of the high-density foam pads on the bottom of the tray, AND to the shower area floor with a 10mm notched-trowel.

NOTE

All on-site specifications and conditions are to comply with the respective adhesive manufacturer's specifications and recommendations. Impresa Tile Showers Ltd. does not imply nor provide any warranties for any tile adhesive listed herein.
